

SP-606 Backup Load Procedure

FORMAT A CF CARD IN THE SP-606:

1. Insert a CF card into the SP-606.
2. Press and hold FUNC, then press PAD 10.
3. Select "CARD FORMAT", then press ENTER.
4. Press F3 twice to execute CARD FORMAT.

COPY THE DATA FILES TO THE CARD WITH YOUR COMPUTER:

1. Uncompress the zipped file.
2. Insert the CF card into a CF adapter or card reader.
3. Copy the ROLAND folder to the CF card.
4. Un-mount the CF card.

UNPROTECT THE SP-606 -

Pattern Protect:

1. Insert the CompactFlash card into the SP-606.
2. Press MENU.
3. "1:SYSTEM" should be highlighted.
4. Press ENTER.
5. Cursor down to select Preload Ptn: PROTECT.
6. Turn VALUE Wheel left to select Preload Ptn: WRITABLE.
7. Press EXIT.

Bank Protect:

1. Press MENU.
2. Cursor down to select "3:Pad Bank Protect."
3. Press ENTER.
4. Press F1 "PRTCT."
5. Repeat for PADBANK 02, 03, and 04 until all PADBANKS are unprotected.
6. Press EXIT.

RESTORE THE DATA:

1. While holding FUNC press Velocity Pad 10, "CARD UTIL."
2. Press F2 "LOAD."
3. "Backup 1" should be highlighted.
4. Press F3 "EXEC."
5. SP-606 will display "Now Executing...Keep Power On."
6. When "Please Power Off" is displayed, turn machine off.